Installation Instructions

TBX-3LC Power Connection Boot Kit

Applications

The TBX-3LC Boot Kit is used for power connection of BSX, RSX, TSX, VSX self-regulating heating cables.

Kit Contents:

Item	Qty	Description
1	1	Power Connection Boot
2	1	RTV Tube






Tools Required




Warnings

- Due to the risk of electrical shock, arcing and fire caused by product damage or improper usage, installation or maintenance, a ground-fault protection device is required.
- Installation must comply with Thermon requirements (including form PN 50207U for Ex systems) and be installed in accordance with the NEC, CEC, or any other applicable national and local codes.
- Component approvals and performance ratings are based on the use of Thermon specified parts only.
- Keep ends of heating cable and kit components dry before and during installation.






Separate braid strands and pull cable through opening in braid. Twist braid into a pigtail. Trim ends of braid.







Cut and remove primary insulation jacket. Omit this **4** step for VSX cable.

2







Thermon Europe B.V.

Boezemweg 25 • 2461 KG Pijnacker • The Netherlands Phone: +31 (0) 15-36 15370



Thermon Manufacturing Company

100 Thermon Drive • P.O. Box 609 • San Marcos, Texas 78667-0609 Phone: (512) 396-5801 • Fax: (512) 396-3627 • 1-800-820-HEAT www.thermon.com