



# CrankCase Heater 240V Self Regulating Cable INSTALLATION PROCEDURES

1. Wrap CCH around casing as many times as possible. Can be overlapped without damage to increase coverage.



2. Feed plastic strip into the locking slot in the cable tie. Tighten cable to secure CCH to the crankcase.



3. Connect CCH to power. A 240 Volt supply with 30mA earth leakage protection is mandatory.